

Introduction

This installation manual will help to setup a Yeastar PBX configuration with a MachCloud provided SIP trunk.


This manual assumes that the following is available.

- An operational Yeastar Phone System with admin rights.
- A MachCloud SIP Trunk that has at least one phone number assigned to it.

Installation steps


Follow the steps to add a MachCloud Trunk to the Yeastar PBX.

1. Login into the Yeastar Management Console with administrator privileges via a web browser and select in the menu: Extension and Trunk > Trunk > Add




Installation manual for using Yeastar with MachCloud

2. Select from dropdown ITSP menu: MachCloud. This will fill-in all relevant Yeastar settings to be able to use MachCloud SIP Trunk.



3. Enter a name for this MachCloud Trunk and check if it is set to 'Enabled'



4. In the details section: fill-in following information

Transport: UPD

Hostname/IP: voice.machcloud.com


Port: 5060

Domain: voice.machcloud.com

Username: <the name of your MachCloud Trunk>

Password: <password of your MachCloud Trunk>

And click "Save" to confirm




Installation manual for using Yeastar with MachCloud


5. You may check in tab "Advanced" the following settings

Voip Settings

- DTFM mode: Inband
- T.38 Support




6. In tab "DIDs/DDIs" you can add/check Phone Numbers which are present at the Trunk




Installation manual for using Yeastar with MachCloud

7. In tab "Inbound Caller Reformatting" no entry needed




8. In tab "Outbound Caller ID" no entry needed



9. In tab " SIP Headers" you can check following settings:

- Get Caller ID From: Follow System
- Get DID Fron: Follow System
- 100ref: Disabled



Installation manual for using Yeastar with MachCloud

That's it. Hope you enjoy using the MachCloud Trunks.

(Source: Yeastar_MachCloud_Trunk_settings_EN_v1.1.docx, 2024-07-17)

MachCloud Knowledgebase

<https://kb.machcloud.com/Knowledgebase/50063/Installation-manual-for-using-...>